



Collection 2017

ORIGINALS - SPECIALS



ORIGINALS









Luville Express	4
Molendam	15
Schneewald	30
Ville de Reidy	45
Sledgeholm	59
Animals	72
Farm Life	75
Fun with Snow and Ice	76
Santa's	81
Traveling	85
Snowman	83
At the Water	87
Village Life	88
Basics	93
Bridges	94
Fences	95
Fire	96
Traveling	97
Lanterns	98
Light Chains	101
Spots	104
Adapters and Spare Bulbs	105
Bestsellers	107
Trees with Lights	110
Group of Trees	112
Trees in Barrel	114
Deciduous Trees	115

SPECIALS

Villages Animated	120
General Animated	127
Houses	131
Figurines	138
Sceneries	139
Stalls	144
Table pieces	147
Adapters	151

Efteling	153
----------	-----

Explanation of icons

 Battery operated	 Rotating item
 Led lighted	 Moving item
 Lighted flame	 Flashing lights
 With music	 Twinkling lights

Attention

The items shown and the descriptive specifications are the copyright of Edelman B.V. and may not be copied or reproduced without the required permission. Colour of the photographed models in the catalogue may deviate from the colours of the products due to lighting variations and the photographic session. Whilst every effort is made to ensure accuracy in this catalogue, mistakes do occur.



ORIGINALS



SPECIALS





NEW

1031274
Fish restaurant

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



NEW

1031275
Dock house

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)





NEW



1031272
Sorting the fish



NEW



1031276
Harbor guard



NEW



1031273
Flying a kite



NEW



1031277
Whale watching



NEW



1031270
Seal and pup



NEW



1031271
Wallrus and pup

Express



NEW



1031278
Harbor ditch



NEW



1031279
Carrying a boat



NEW



1031280
Hoist with pulley



NEW



1031281
Pulling the boat

Express




1015141
Petit art gallery

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



8 718861 14647 9



2 x 1.5 V AA



612023
Telegram kiosk

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



8 712799 92205 1



2 x 1.5 V AA



1015186
Elsie and Pieter romance



1015184
Asking for directions



611089
Kissing goodbye





1015187
At the gas pump



611090
Railway guard
Felix



612074
Markus on
the telephone



1015185
Dennis is
painting





1015130
Eiffel Tower

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



8 718861 14636 3



2 x 1.5 V AA



1015142
Travelling with car

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



8 718861 14648 6



2 x 1.5 V AA



1015144
Motorcycle

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



2 x 1.5 V AA



1015143
Ville map

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



2 x 1.5 V AA



611100
Track pointer



1015169
Car sign



1015170
City sign



611098
Station clock






ANIMATED

**1015151
Propeller plane**

led lighting battery operated with adapter connection fits to 4,5 v transformer 610302 (adapter not included)




3 x 1.5 V AA



ANIMATED

**612036
Hot air balloon**

led lighting battery operated with adapter connection fits to 4,5 v transformer 610302 (adapter not included)



3 x 1.5 V AA

Express






ANIMATED

612000
Farm shed

led lighting battery operated with adapter connection fits
to 4,5 v transformator 610302 (adapter not included)



NEW

1031286
Goat cheese

led lighting battery operated with adapter connection fits
to 3 V transformator 610300 (adapter not included)



Molendam



ANIMATED


610009

Chicken farm kukeleku

led lighting battery operated with adapter connection fits to 4,5 v transformator 610302 (adapter not included)



8 712799 21881 9



3 x 1.5 V AA



ANIMATED


1015123

Vegetable farm

led lighting battery operated with adapter connection fits to 4,5 v transformator 610302 (adapter not included)



8 718861 14629 5



3 x 1.5 V AA



ANIMATED

611027
Cheese farm


led lighting battery operated with adapter connection fits
to 4,5 v transformator 610302 (adapter not included)



8 712799 61786 5



3 x 1.5 V AA



8 712799 92191 7

612009
Greenhouse



8 718861 14688 2

1015182
Chicken farmer



8 712799 21915 1

610042
Little chicken farm



ANIMATED

612038

Skipping rope

led lighting battery operated with adapter connection fits to 4,5 v transformator 610302 (adapter not included)



8 712799 92220 4



3 x 1.5 V AA



NEW

1031284

Dutch church

led lighting battery operated with adapter connection fits to 3 V transformator 610300 (adapter not included)



8 718861 30438 1



2 x 1.5 V AA




Molendam



NEW

1031285
Bike for rent

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



NEW


1031282
Bicycle, set of 2



NEW

1031287
Dutch home

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



Molendam




NEW

1031289

Cheese market

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



2 x 1.5 V AA



NEW

1031290

Wooden clogs

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



2 x 1.5 V AA

Molendam




NEW

1031291

Stroopwafel market

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)




ANIMATED

1015145

Ice skating competition

led lighting battery operated with adapter connection fits to 4,5 v transformer 610302 (adapter not included)



Molendam




ANIMATED

608215
Forest skating pond
 lighting adapter included AC 12V



1015128
Hot drinks on ice
 led lighting battery operated with adapter connection fits
 to 3 V transformer 610300 (adapter not included)



Molendam




612006

Ice skate service

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 712799 92184 9



2 x 1.5 V AA




610045

Stempelpost

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 712799 21919 9



2 x 1.5 V AA






611095
Ice bridge

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



8 712799 61858 9



2 x 1.5 V AA



1015129
Ice skating stage

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



8 718861 14635 6



2 x 1.5 V AA



1015180
Ice skating with friend



1015181
Ice skater Ties



612070
Hendrik on ice skates

Molendam



612071
Lies and Janus on ice
skates



NEW



1031283
Learn to skate



608258
The sledge parade,
set of 3



1015178
Fun on sledge

ANIMATED

611040
Snowman with children

led lighting battery operated with adapter connection fits
to 4,5 v transformer 610302 (adapter not included)



3 x 1.5 V AA



Molendam



ANIMATED

610017
Farmers mill
lighting adapter included AC 12V



ANIMATED

609092
The dutch tulip mill
lighting adapter included AC 12V



Molendam



ANIMATED

612028
Tourist mill
lighting adapter included AC 12V



NEW ANIMATED


1031288
Dutch mill
led lighting battery operated with adapter connection fits
to 4,5 v transformer 610302 (adapter not included)







611054
Pretzel market
 led lighting battery operated with adapter connection fits
 to 3 V transformator 610300 (adapter not included)



610034
Christmas market
 led lighting battery operated with adapter connection fits
 to 3 V transformator 610300 (adapter not included)





610115

Christmas market

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



8 712799 21996 0



2 x 1.5 V AA



611053

Ski route

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



8 712799 61812 1



2 x 1.5 V AA



ANIMATED

1015125

Ski hotel


led lighting battery operated with adapter connection fits to 4,5 v transformer 610302 (adapter not included)



8 718861 14631 8



3 x 1.5 V AA



612014

Ski rental

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 712799 92196 2



2 x 1.5 V AA





610116

Christmas market

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



2 x 1.5 V AA



1015127

Skicafe

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



2 x 1.5 V AA



NEW



1031298
Piste break



609113
Ski jumper, set of 2



608249
Ski class, set of 3



1015177
Andre is skiing



612065
Ski school



NEW



1031295
Snowboarder, set of 2






1015126

Waiting for skilift

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 718861 14632 5



2 x 1.5 V AA



1015137

Entry ski alm

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 718861 14643 1



2 x 1.5 V AA



ANIMATED


611032

Kabelbahn mountain

lighting adapter included AC 12V



8 712799 61791 9



Schneewald



612066
Rudolph skiing



1015158
Ski flag, set of 3



NEW



1031297
Ski rescue



NEW



1031292
Saint Bernard



NEW



1031293
Rescued skier



NEW



1031294
Ski fall


Schneewald



ANIMATED

1015146
Ski class


led lighting battery operated with adapter connection fits
to 4,5 v transformator 610302 (adapter not included)



NEW

1031296
Ski patrol

led lighting battery operated with adapter connection fits
to 3 V transformator 610300 (adapter not included)



Schneewald



611045
Priest chapel

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



608290
Chapel

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



1015148
Santa swing

led lighting battery operated with adapter connection fits to 4,5 v transformer 610302 (adapter not included)



Schneewald



1015179
Backpacker Ralf



1015138
Christmas tree selling



603023
Santa reindeer sledge



612016
Forest barbecue
led lighting battery operated with adapter connection fits
to 3 V transformator 610300 (adapter not included)



1015134
Camp
led lighting battery operated with adapter connection fits
to 3 V transformator 610300 (adapter not included)





ANIMATED

611043
Skating and skiing cave
 lighting adapter included AC 12V



ANIMATED

610016
Winter sport mountain
 lighting adapter included AC 12V



Schneewald



ANIMATED

1015147

Childrens garden


led lighting battery operated with adapter connection fits to 4,5 v transformator 610302 (adapter not included)



8 718861 14653 0



3 x 1.5 V AA



ANIMATED

1015150

Air balloon

led lighting battery operated with adapter connection fits to 4,5 v transformator 610302 (adapter not included)



8 718861 14656 1



3 x 1.5 V AA



ANIMATED

610018

Santa flying

lighting adapter included AC 12V



8 712799 21890 1



Schneewald



ANIMATED

603038
Ski lift
lighting adapter included AC 12V



ANIMATED

604011
Ski slope
lighting adapter included AC 12V



Schneewald




ANIMATED

612032
Santa's shop

led lighting battery operated with adapter connection fits to 4,5 v transformer 610302 (adapter not included)



8 712799 92214 3



3 x 1.5 V AA




ANIMATED

612029
Santa's workshop

led lighting battery operated with adapter connection fits to 4,5 v transformer 610302 (adapter not included)



8 712799 92211 2



3 x 1.5 V AA





1015133

Bistro

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 718861 14639 4



2 x 1.5 V AA



8 718861 14677 6

1015171

Eating lobster






612011

Wine tasting shop

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 712799 92193 1



2 x 1.5 V AA



NEW

1031302

Winery

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 718861 30456 5



2 x 1.5 V AA

Ville de Reidy



NEW

1031305

Making french wine

led lighting battery operated with adapter connection fits to 3 V transformator 610300 (adapter not included)



1015124

Farm ville

led lighting battery operated with adapter connection fits to 3 V transformator 610300 (adapter not included)



NEW

1031307

Stork shed

led lighting battery operated with adapter connection fits to 3 V transformator 610300 (adapter not included)



Ville de Reidy



NEW

ANIMATED

1031309
Music kiosk

led lighting battery operated with adapter connection fits
to 4,5 v transformator 610302 (adapter not included)



8 718861 30463 3



3 x 1.5 V AA



ANIMATED

610030
Carousel

lighting adapter included AC 12V



8 712799 21903 8



Ville de Reidy



609153
Waterpump




611051
Pigeon house
led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



ANIMATED

610025
Forest swing
led lighting battery operated with adapter connection fits
to 4,5 v transformer 610302 (adapter not included)





ANIMATED

**610008
Church**

lighting adapter included AC 12V



**1015136
Pastor chapel**

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



**610003
Church St Chevalier**

led lighting battery operated with adapter connection fits to 4,5 v transformer 610302 (adapter not included)



Ville de Reidy



NEW

1031303
French bakery

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



NEW

1031306
Vintage market

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



611048
Poulier market

led lighting battery operated with adapter connection fits to 4,5 v transformer 610302 (adapter not included)



Ville de Reidy




1015131
Fish market

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



8 718861 14637 0



2 x 1.5 V AA




NEW

1031304
Selling french bread

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



8 718861 30458 9



2 x 1.5 V AA



Ville de Reidy



NEW


1031308

French cheese market

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 718861 30462 6



2 x 1.5 V AA



NEW

1031299

Buying a baguet



8 718861 30453 4

Ville de Reidy



611020
Donkey farm

led lighting battery operated with adapter connection fits to 4,5 v transformator 610302 (adapter not included)



ANIMATED

611021
Black smith

led lighting battery operated with adapter connection fits to 4,5 v transformator 610302 (adapter not included)






1015140
Farm ville

led lighting battery operated with adapter connection fits
to 3 V transformator 610300 (adapter not included)



8 718861 14646 2



2 x 1.5 V AA



8 712799 92194 8

612012
Donkey go

Ville de Reidy



NEW



1031300
Shepherd



1015173
Feeding the farm
animals



1015139
Little farm scenery



1015174
Walking to the farm



NEW

1031301
Silo

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



2 x 1.5 V AA

Ville de Reidy




ANIMATED

609090
Farm mill
lighting adapter included AC 12V



ANIMATED

610019
Grain mill
lighting adapter included AC 12V



Ville de Reidy





NEW

1031324

Little home

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



2 x 1.5 V AA



NEW

1031315

Dressing snowman

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



2 x 1.5 V AA



NEW

1031333

Plundering the christmas tree

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



2 x 1.5 V AA

Slegdehølm



NEW



1031318
Girl and reindeer



NEW



1031317
Collecting a
christmas tree



NEW

1031322
Christmas tree shop

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



2 x 1.5 V AA




NEW

ANIMATED

1031327

Sint Lucia church

led lighting battery operated with adapter connection fits to 4,5 v transformer 610302 (adapter not included)



NEW

1031328

Priest church

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



NEW

1031331

Sint Lucia

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



Slegdehølm



NEW

ANIMATED

1031326
Visit Santa

led lighting battery operated with adapter connection fits
to 4,5 v transformator 610302 (adapter not included)



8 718861 30480 0



3 x 1.5 V AA



NEW

1031330
Santa is decorating



8 718861 30484 8



NEW

ANIMATED

1031323
Deer farm

led lighting battery operated with adapter connection fits
to 4,5 v transformator 610302 (adapter not included)



NEW



1031313
Reindeer, set of 2



NEW



1031311
Track pointer Santa

Slegdehølm



NEW

1031336
Reindeer sleigh

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)




2 x 1.5 V AA



NEW

1031337
Reindeer shop

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



2 x 1.5 V AA

Slegdehølm



NEW



1031319
Madam Fur



NEW

1031338
Winter clothes shop
led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



2 x 1.5 V AA



NEW



1031316
Buying lachs



NEW

1031339
Selling lachs

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



2 x 1.5 V AA

Slegdeholm



NEW

1031325

Forest lodge

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



8 718861 30479 4



2 x 1.5 V AA



NEW

1031332

Bonfire

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



8 718861 30486 2



2 x 1.5 V AA



NEW

1031334

Tipi

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



8 718861 30488 6



2 x 1.5 V AA



NEW

1031320

Karen and Eva with
flying star




8 718861 30474 9



NEW

1031310
Swedish fire

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



2 x 1.5 V AA



NEW



1031329
Fishing



NEW



1031321
Fun with snow

Slegdehølm




NEW

1031335
Iglo camping

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



8 718861 30489 3



2 x 1.5 V AA



NEW



8 718861 30466 4

1031312
Bear and cub, set of 2



NEW



8 718861 30468 8

1031314
Wolve, set of 2





NEW



1031313
Reindeer, set of 2



612081
Deer, set of 2



603044
Deer drinking



NEW



1031292
Saint Bernard



1015192
Dog Tubbs



NEW



1031270
Seal and pup

Animals



NEW



1031271
Wallrus and pup



NEW



1031312
Bear and cub, set of 2



NEW



1031314
Wolve, set of 2



1015189
Pig and piglets,
set of 2



1015191
Donkey and foal,
set of 2



1015190
Goat and kid,
set of 2



612079
Cow and bull,
set of 2

Animals



612012
Donkey go



NEW



1031300
Shepherd



1015173
Feeding the
farm animals



1015174
Walking to the farm



609100
Farm scenery, set of 4



1015182
Chicken farmer



1015139
Little farm
scenery





1015180
Ice skating with friend



1015181
Ice skater Ties



612070
Hendrik on ice skates



612071
Lies and Janus
on ice skates



NEW



1031283
Learn to skate



608258
The sledge parade,
set of 3

Fun with Snow and Ice



1015178
Fun on sledge



608250
Frank with teddy
on the sledge



610064
Rob and Tom's
snowfight



1031321
Fun with snow

NEW

Fun with Snow and Ice




611053
Ski route

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



8 712799 61812 1



2 x 1.5 V AA



8 712799 83225 1

609113
Ski jumper, set of 2



8 711473 76679 0

608249
Ski class, set of 3

Fun with Snow and Ice



1015177
Andre is skiing



612065
Ski school



NEW



1031295
Snowboarder, set of 2



612066
Rudolph skiing



NEW



1031298
Piste break

Fun with Snow and Ice



NEW



1031297
Ski rescue



NEW



1031293
Rescued skier



NEW



1031294
Ski fall



1015158
Ski flag, set of 3



NEW



1031311
Track pointer Santa

Fun with Snow and Ice



NEW



1031330
Santa is decorating



612082
Happy Santa



604023
Santa skiing



603024
Santa with gifts



610062
Santa checking his list



603023
Santa reindeer sledge

Santa



1015188
Santa takes a photo



612083
Santa and deers



602568
Santa with deer



610041
Reindeer teasing Santa



611086
Santa's gift box



1015135
Presents from Santa






NEW

1031315
Dressing snowman

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



8 718861 30469 5



2 x 1.5 V AA



611106
Snowman lighted

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



8 712799 61874 9



2 x 1.5 V AA



1015176
Dog teasing snowman



610063
Metty the snowman



608246
Ana and Mr snowman



608247
Tom and grandfather
in the snow

Snowman



1015186
Elsie and Pieter
romance



1015184
Asking for directions



611089
Kissing goodbye



1015187
At the gas pump



611090
Railway guard Felix



612074
Markus on the
telephone

Traveling



1015143
Ville map

led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



Traveling



NEW



1031277
Whale watching



NEW



1031276
Harbor guard



NEW



1031278
Harbor ditch



NEW



1031279
Carrying a boat



NEW



1031280
Hoist with pulley



NEW



1031281
Pulling the boat

At the water



NEW

1031333

Plundering the christmas tree

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



2 x 1.5 V AA



NEW



1031318

Girl and reindeer



1015175

Carrying a tree



1015179

Backpacker Ralf



NEW



1031329

Fishing

Village Life



NEW



1031317
Collecting a
christmas tree



NEW



1031319
Madam Fur



NEW



1031316
Buying lachs



NEW



1031272
Sorting the fish



NEW



1031273
Flying a kite



NEW



1031320
Karen and Eva with
flying star

Village Life



1015185
Dennis is
painting



NEW



1031299
Buying a baguet



1015171
Eating lobster



603067
Ann and Hein
building





NEW

1031331

Sint Lucia

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 718861 30485 5



2 x 1.5 V AA




609132

Lantern lighter

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 712799 83254 1



2 x 1.5 V AA



Village Life



609153
Waterpump



1015449
Wooden log fence



600389
Village well



1015448
Wooden log fence



611195
Birdcage with old English streetlantern
led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



2 x 1.5 V AA



Village Life



605135
Lawn mat with snow



600366
Stone bridge with deer



8 711473 03537 7



NEW

1035464
Bridge with lights
led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



8 718861 34221 5



2 x 1.5 V AA



NEW

1035465
Stone bridge



8 718861 34222 2

Bridge



611187

Bristle trees on stone wall

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



612114

Lighted fence

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



605052

Wooden fence



612113

Lighted fence

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



612115

Lighted fence

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



611192

Lighted gate

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



Fence



1015157

Brazier

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 718861 14663 9



2 x 1.5 V AA




1015152

Chimenea

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 718861 14658 5



2 x 1.5 V AA



1015153

Fire basket

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 718861 14659 2



2 x 1.5 V AA



610093

Little fire

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 712799 21974 8



2 x 1.5 V AA



609184

Fire chasing

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 717669 88730 0



2 x 1.5 V AA

NEW




1031310

Swedish fire

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 718861 30464 0



2 x 1.5 V AA



610040

Nature campfire

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 712799 21913 7



2 x 1.5 V AA

Fire



NEW



1031282
Bicycle, set of 2



611100
Track pointer



1015169
Car sign



1015170
City sign



611098
Station clock



611193
Traffic light, set of 2
led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



2 x 1.5 V AA



Traveling




605149

Lantern, set of 4

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 711473 05041 7



2 x 1.5 V AA




605127

Gas street lantern, set of 4

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 711473 05018 9



2 x 1.5 V AA




605126

Street lantern, set of 4

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 711473 05017 2



2 x 1.5 V AA

Lanterns



610180

Wooden street lantern, set of 4

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 712799 36174 4



2 x 1.5 V AA



612051

Street lantern on foot, set of 3

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 712799 92233 4



2 x 1.5 V AA



1015159

Forrest lanterns, set 3

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 718861 14665 3



2 x 1.5 V AA

Lanterns



612118

Lantern, set of 2

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 712799 92300 3




2 x 1.5 V AA



605132

Old English street lantern, set 2

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 711473 05023 3



2 x 1.5 V AA



612052

Classic lantern on foot, set of 2

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 712799 92234 1



2 x 1.5 V AA


Lanterns



1025887
24 warm white lights, steady
 led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



1025881
36 warm white lights, steady
 led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



605106
36 Mini white lights, steady
 led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



1025888
24 blue lights, steady
 led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



1025882
36 blue lights, steady
 led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



1025883
12 warm white lights, steady
 led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)





NEW



1025877
36 warm white lights, twinkling
 led lighting battery operated with adapter
 connection fits to 3 V transformer 610300
 (adapter not included)



NEW



1025879
36 white lights, twinkling
 led lighting battery operated with adapter
 connection fits to 3 V transformer 610300
 (adapter not included)



NEW



1025878
36 blue lights, twinkling
 led lighting battery operated with adapter
 connection fits to 3 V transformer 610300
 (adapter not included)



NEW



1025876
36 multicolour lights, twinkling
 led lighting battery operated with adapter
 connection fits to 3 V transformer 610300
 (adapter not included)



Light Chains



NEW



1025880
36 warm white lights, chasing
 led lighting battery operated with adapter
 connection fits to 3 V transformer 610300
 (adapter not included)



605090
36 Mini blue lights, chasing
 led lighting battery operated with adapter
 connection fits to 3 V transformer 610300
 (adapter not included)



605091
36 Mini white lights, chasing
 led lighting battery operated with adapter
 connection fits to 3 V transformer 610300
 (adapter not included)



610120
Chinese lantern light chain multicolour
 led lighting battery operated with adapter
 connection fits to 3 V transformer 610300
 (adapter not included)



Light Chains




NEW

1025885

Spot light warm white, set of 3

led lighting battery operated with adapter connection fits to 4,5 v transformer 610302 (adapter not included)



NEW

1025886

Spot light blue, set of 3

led lighting battery operated with adapter connection fits to 4,5 v transformer 610302 (adapter not included)



NEW

1025884

Spot light multicolor, set of 3


led lighting battery operated with adapter connection fits to 4,5 v transformer 610302 (adapter not included)



610155

Spot light warm white, set of 2


led lighting battery operated with adapter connection fits to 4,5 v transformer 610302 (adapter not included)



1015167

Spot light blue, set of 2


led lighting battery operated with adapter connection fits to 4,5 v transformer 610302 (adapter not included)



1015168

Spot light multicolour, set of 2

led lighting battery operated with adapter connection fits to 4,5 v transformer 610302 (adapter not included)



Spots



605523
Replacement bulb E10 12V, set of 2



8 711473 03955 9



609179
Spare bulb warm white, set of 4



8 717669 88725 6



609178
Spare bulb warm white, set of 2



8 717669 88724 9



609180
Spare bulb warm white, set of 6



8 717669 88726 3

Adapters and Spare Bulbs



609177

Light bulb

led lighting battery operated with adapter connection fits to 4,5 v transformer 610302 (adapter not included)



610300

3 volt switch adaptor 3 volt with 4 plugs out



610302

4,5 volt switch adaptor with 4 plugs out



610153

Chain of 3 light bulbs
adapter included dc 4,5v



610301

12 volt light cord volt with switch adaptor



610303

12 volt 10 din light system with switch adaptor



Adapters and Spare Bulbs



605004
Bristle tree mini H 7,5
cm , set of 4



605003
Bristle tree H 10 cm,
set of 2



605002
Bristle tree H 15 cm



605001
Bristle tree H 23 cm



605000
Bristle tree H 30,5 cm



608319
Bristle tree assorted,
set of 9

Bestsellers



605006
Bristle tree assorted,
set of 12



605005
Bristle tree assorted,
set of 21

NEW



1015154
Bristle tree on log
H 20 cm



1025898
Bristle tree on log
assorted, set of 6

NEW



605020
Evergreen tree
H 30,5 cm



1025904
Buxus bush H 4,5 cm,
set of 4

Bestsellers



608318
Evergreen tree assorted,
set of 9



608320
Tree white assorted,
set of 9



609176
Tree evergreen assorted,
set of 12



609158
Evergreen tree assorted,
set of 21



609159
Tree white assorted,
set of 21

Bestsellers



NEW



1025908

Frosted tree with lights H 30 cm

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 718861 25030 5



2 x 1.5 V AA

NEW



1025909

Frosted tree with lights H 22,5 cm, set of 2

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 718861 25031 2



2 x 1.5 V AA

NEW



1025910

Frosted tree with lights H 14,5 cm, set of 3

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 718861 25032 9



2 x 1.5 V AA

NEW



1025905

Tree with lights H 30 cm

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 718861 25027 5



2 x 1.5 V AA

NEW



1025906

Tree with lights H 22,5 cm, set of 2

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 718861 25028 2



2 x 1.5 V AA

NEW




1025907

Tree with lights H 14,5 cm, set of 3

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 718861 25029 9



2 x 1.5 V AA

Trees with Lights



605143

Christmas tree with lights H 23 cm

led lighting battery operated with adapter connection fits to 4,5 v transformer 610302 (adapter not included)



605142

Christmas tree with lights H 15 cm


led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



608312

Christmas tree with lights H 15 cm, set of 3

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



608311

Tree with lights H 23 cm

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



608310

Tree with lights H 15 cm, set of 2

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



Trees with Lights



NEW



1025894

3 Snowy trees on base white light H 12 cm

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 718861 25016 9



2 x 1.5 V AA

NEW



1025893

3 Snowy trees on base white light H 19 cm

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 718861 25015 2



2 x 1.5 V AA

NEW



1025896

3 Trees on bases multicolour light H 12 cm

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 718861 25018 3



2 x 1.5 V AA

NEW




1025895

3 Trees on bases multicolour light H 19 cm

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 718861 25017 6



2 x 1.5 V AA

NEW



1025897

6 Trees on bases multicolour lights H 20,5 cm

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 718861 25019 0



2 x 1.5 V AA

Group of Trees



609165

3 Trees on base with white light H 19 cm

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 717669 88711 9



2 x 1.5 V AA



609164

6 Trees on base with white light H 19 cm

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 717669 88710 2



2 x 1.5 V AA



609163

6 Trees on base with multicolor light H 19 cm

led lighting battery operated with adapter connection fits to 3 V transformer 610300 (adapter not included)



8 717669 88709 6



2 x 1.5 V AA



609162

6 Trees base multicolor light fibre optic H 19 cm

led lighting battery operated with adapter connection fits to 4,5 v transformer 610302 (adapter not included)



8 717669 88708 9



3 x 1.5 V AA



Group of Trees



612054
Buxus bush in barrel H 7 cm, set of 2



612103
Buxus tree in barrel H 10 cm, set of 2



612055
Buxus bush in barrel H 7 cm, set of 2
led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



NEW

1025899
Buxus tree in a barrel H 8,5 cm, set of 2
led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



612050
Fibre optic lighted christmas tree in barrel
H 9,5 cm, set of 2
led lighting battery operated with adapter connection fits
to 3 V transformer 610300 (adapter not included)



Trees in Barrel



609183
Lighted tree with multicolour light H 23 cm
 led lighting battery operated with adapter connection fits
 to 3 V transformer 610300 (adapter not included)



8 717669 88729 4



2 x 1.5 V AA



605080
Lighted shimmering twig fibre optic H 17,5 cm
 led lighting battery operated with adapter connection fits
 to 3 V transformer 610300 (adapter not included)



8 711473 03896 5



2 x 1.5 V AA

Deciduous trees



NEW



1025901
Mountain pine H 16 cm



NEW



1025902
Mountain pine H 23 cm



NEW



1025903
Mountain pine H 30 cm



605009
Mountain pine H 10 cm,
set of 2



NEW



1025900
Mountain pine H 12 cm,
set of 2

Deciduous trees



605050
Winter alaska pine
H 15 cm



605049
Winter alaska pine
H 23 cm



605048
Winter alaska pine
H 30,5 cm

Deciduous trees



NEW



1031344
Willow tree H 15 cm



NEW



1031343
Willow tree H 22,5 cm



NEW



1031345
Tree H 18 cm



NEW



1031346
Tree H 23 cm



NEW



1031348
Tree H 16 cm



NEW



1031347
Tree H 23 cm

Deciduous trees





NEW

ANIMATED

1025847
Christmas scenery, 2 assorted



8 718861 24969 9



2 x 1.5 V AA




NEW

ANIMATED

1028570
Christmas village, 3 assorted



8 718861 27707 4



3 x 1.5 V AA

Villages animated



NEW

ANIMATED

1025866

Town with children playing, 3 assorted
with adapter connection fits to transformer 611132
(adapter not included)



8 718861 24988 0



3 x 1.5 V AA

NEW


ANIMATED

1025850

Christmas house, 2 assorted
with adapter connection fits to transformer 611132
(adapter not included)



8 718861 24972 9



3 x 1.5 V AA

Villages animated



NEW

ANIMATED


1025849
Christmas house, 2 assorted
with adapter connection fits to transformer 611132
(adapter not included)



8 718861 24971 2



3 x 1.5 V AA



NEW

ANIMATED


1025870
Town with children skating, 2 assorted
with adapter connection fits to transformer 611132
(adapter not included)



8 718861 24992 7



3 x 1.5 V AA




Villages animated




NEW **ANIMATED**

1035255
Christmas house



ANIMATED

612092
Church with revolving kids
with adapter connection fits to transformer 611132
(adapter not included)




Villages animated




NEW **ANIMATED**

1036162
Winter fun



ANIMATED

1015630
Christmas village, 2 assorted
with adapter connection fits to transformer 611132
(adapter not included)



Villages animated



ANIMATED

1013993
Christmas village with train
adapter included dc 4,5v



Villages animated




ANIMATED

611013
Village with reindeers
adapter included dc 4,5v



ANIMATED

1014006
Christmas village, fibre optic
adapter included 6 V




Villages animated



ANIMATED


1015628
Gazebo, 2 assorted



NEW

ANIMATED

1035254
Snowboarding




General Animation



ANIMATED


1013997
 Santa cart
 with adapter connection fits to transformer 611132
 (adapter not included)



NEW

ANIMATED

1035253
 Carousel



General Animation




ANIMATED

1014003
Village with ferris wheel
 with adapter connection fits to transformer 611132
 (adapter not included)



ANIMATED

612094
Mountain sledge
 adapter included dc 4,5v





ANIMATED

1015613
Ski slope
adapter included dc 4,5v



NEW

ANIMATED

1025869
Ski fun
adapter included dc 4,5v



General Animation



NEW

1036022
Christmas house,
5 assorted



2 x AG13



NEW

1025863
Town,
4 assorted



3 x AG10



NEW

1028573
Nordic house,
3 assorted




2 x AG13

Houses




NEW

1028574
Nordic church,
2 assorted




NEW

1028571
Holland church,
2 assorted



NEW


1028572
Holland house,
3 assorted



Houses




1014008
Christmas house,
4 assorted




NEW

1028578
Nordic house,
3 assorted



NEW

1028579
Nordic church,
2 assorted




Houses




NEW

1028576
Holland church,
2 assorted



NEW

1028577
Holland windmill,
2 assorted



NEW

1028575
Holland house,
3 assorted




Houses




NEW

1025853
Church with warm white light
2 assorted




NEW

1025855
House with warm white light
4 assorted



NEW

1025854
Church with multicolour light
2 assorted




Houses



NEW

1025856
House with multicolour light
4 assorted




NEW

1025857
Church,
2 assorted



NEW

1025858
Town,
4 assorted



Houses



NEW

1025864
House with fiber optic,
4 assorted



NEW

1025865
Church with fibre optic



NEW

1025859
House, 2 assorted
with adapter connection fits
to transformer 611132 (adapter not included)



Houses



NEW



1025890
Christmas shopping,
set of 4



NEW



1025891
Building a snowman,
set of 4



NEW



1025892
Playing with Santa,
set of 5



NEW



1035247
Santa scenery,
2 assorted, set of 6



NEW




1035248
Winter scenery,
2 assorted, set of 6

Figurines



NEW

1025845
Christmas scenery,
4 assorted



NEW

1025846
Christmas scenery,
2 assorted



NEW

1035252
Winter scenery,
4 assorted



Sceneries



1014005
Christmas scenery,
4 assorted




2 x 1.5 V AAA

Sceneries



612085
Winter scenery,
4 assorted



NEW


1028580
Christmas scenery,
4 assorted



NEW

ANIMATED

1025872
Children on swing,
2 assorted




Sceneries



ANIMATED

612090
Skating pond, 2 assorted
with adapter connection fits to transformer 611132
(adapter not included)



ANIMATED


1025871
Santa and tree,
2 assorted



NEW

ANIMATED

1025868
Christmas scenery, 2 assorted
with adapter connection fits to transformer 611132
(adapter not included)



Sceneries



ANIMATED

1013992
Winter scenery, 2 assorted
with adapter connection fits to transformer 611132
(adapter not included)




Sceneries



NEW

1028581
Nordic market,
3 assorted




NEW

1028582
Holland market,
3 assorted




NEW

1035249
Stall,
3 assorted




NEW

1028583
Christmas market,
3 assorted





1013999
Tree shop
 with adapter connection fits to transformer 611132
 (adapter not included)




NEW

1025889
Market stall, 4 assorted
 with adapter connection fits to transformer 611132
 (adapter not included)



ANIMATED

612137
Village fair scenery, 3 assorted
 with adapter connection fits to transformer 611132
 (adapter not included)



Stalls



NEW

1025861
Market stall christmas trees,
2 assorted
with adapter connection fits to transformer 611132
(adapter not included)



NEW

1025862
Market stall trees and florist,
2 assorted
with adapter connection fits to transformer 611132
(adapter not included)



Stalls



NEW

1025843
Beetle, 3 assorted



NEW

1025844
Truck, 3 assorted



NEW

1035256
Transporting the tree,
2 assorted



Table pieces




NEW

ANIMATED

1035428
Ball with christmas
scenery, 2 assorted



8 718861 34185 0



3 x 1.5 V AAA



NEW

ANIMATED

1035429
Ball with winter
scenery, 2 assorted



8 718861 34186 7



3 x 1.5 V AAA



NEW

1035430
Cover with christmas
scenery, 2 assorted



8 718861 34187 4



3 x 1.5 V AAA

Table pieces



NEW

1035250
Christmas time,
3 assorted



ANIMATED

1015629
Box with scenery,
2 assorted



NEW

1025851
Van with animation,
2 assorted



Table pieces




NEW

ANIMATED




1025860
Christmas tree with animation,
2 assorted



ANIMATED

1014004
Cover with scenery, 2 assorted




NEW

ANIMATED



1025867
Christmas tree with train
with adapter connection fits to transformer 611132
(adapter not included)



NEW

1025852
Santa driving a beetle




Table pieces




611132
Adaptor



811132
Adaptor UK plug

Adapters



SPROOKJESBOS

Efteling





381897
Sprookjesbos



381892
Kleine boodschap



1001359
Prullenmand




Efteling



381650
Prullenbak



NEW



1036354
Brug Tobbelientje



NEW



1036362
Wegwijzer

Sprookjesbos



NEW


1036355

Verlichte boom H 16 cm

led lighting battery operated with adapter connection fits to 3 V transformator 610300 (adapter not included)



8 718861 35040 1



2 x 1.5 V AA



ANIMATED


1001356

Zweefmolen

led lighting battery operated with adapter connection fits to 4,5 v transformator 610302 (adapter not included)



8 718861 00938 5




3 x 1.5 V AA

Efteling



NEW



1036363
Strohuis moeder geit



NEW



1036361
Hek



381651
Paddenstoel

Sprookjesbos

Efteling



1001357
De Magische Klok, set van 2



NEW



1008019
Heraut, set van 2



1001358
Holle Bolle Gijs

Sprookjesbos

Efteling



381940
Holle Bolle Gijs



381886
De wolf



381887
Moeder geit

Sprookjesbos

Efteling



381880

Huis van de Zeven geitjes

led lighting battery operated with adapter connection fits to 4,5 v transformator 610302 (adapter not included)



8 711473 80107 1



3 x 1.5 V AA



NEW

ANIMATED

1008016

Zeven geitjes

led lighting battery operated with adapter connection fits to 4,5 v transformator 610302 (adapter not included)



8 718861 07914 2



3 x 1.5 V AA



NEW



8 718861 07912 8

1008014

Zeven geitjes tafel

Sprookjesbos




381545

Kasteel van Doornroosje

led lighting battery operated with adapter connection fits
to 4,5 v transformator 610302 (adapter not included)



8 711473 01661 1



3 x 1.5 V AA



8 712799 01670 5

381924

Poort Doornroosje

Efteling



1001362
De Tuinman en de Fakir



1001361
De Fakir

Sprookjesbos



381884

Huis van Repelsteeltje

led lighting battery operated with adapter connection fits to 4,5 v transformator 610302 (adapter not included)



8 711473 80145 3



3 x 1.5 V AA



NEW



8 718861 35045 6

1036360

Ridder Repelsteeltje



NEW



8 718861 07911 1

1008013

Repelsteeltje



381646

Huis van Roodkapje

led lighting battery operated with adapter connection fits to 4,5 v transformator 610302 (adapter not included)



8 711473 19203 2



3 x 1.5 V AA



381500

Roodkapje



8 711473 01595 9




381885

Huis van Vrouw Holle

led lighting battery operated with adapter connection fits
to 4,5 v transformator 610302 (adapter not included)



8 711473 80146 0



3 x 1.5 V AA



8 711473 80321 1

381898


Waterput Vrouw Holle



381938

Toren van Raponsje

led lighting battery operated with adapter connection fits to 4,5 v transformator 610302 (adapter not included)




NEW

ANIMATED

1008015

Indische waterlelie

led lighting battery operated with adapter connection fits to 4,5 v transformator 610302 (adapter not included)



Efteling



NEW



1008017
Kleding van de Keizer



NEW

1008018
Huis van Sneeuwwitje
led lighting battery operated with adapter connection fits
to 3 V transformator 610300 (adapter not included)



Sprookjesbos

Efteling



1001363
Klein Duimpje
en de Reus



381895
Ezeltje strekje



NEW



1008012
Langnek



381888
Tobbelientje

Sprookjesbos




381939
Trollenkoning

led lighting battery operated with adapter connection fits
to 4,5 v transformator 610302 (adapter not included)



8 717669 15115 9



3 x 1.5 V AA



1001360
De Draak

led lighting battery operated with adapter connection fits
to 3 V transformator 610300 (adapter not included)



8 718861 00942 2



2 x 1.5 V AA

Efteling



381925
Verlichte straat zwaan kleef
lighting adapter included AC 12V



381645
Huis van de Kabouters
led lighting battery operated with adapter connection fits
to 4,5 v transformator 610302 (adapter not included)




Sprookjesbos



381937
Muziek kabouter in holle boom
 led lighting battery operated with adapter connection fits
 to 4,5 v transformator 610302 (adapter not included)



8 717669 15087 9




3 x 1.5 V AA



381882
Kabouterhuis
 led lighting battery operated with adapter connection fits
 to 3 V transformator 610300 (adapter not included)



8 711473 80143 9



2 x 1.5 V AA

Efteling



381502
Vissende kabouter



381942
Schrijf kabouter



NEW



1036358
Kabouter in de boot



NEW




1036352
Dansende Kabouter

Sprookjesbos



NEW



1036356
Hans en Grietje



NEW



1036353
Oven van Hans en Grietje



NEW

381881

Huis van Hans en Grietje

led lighting battery operated with adapter connection fits
to 3 V transformator 610300 (adapter not included)



2 x 1.5 V AA



NEW



1036359
Bremer stadsmuzikanten




NEW



1036357
De Ganzenhoedster

Efteling



1009187
Waterbal Efteling



NEW



1004955
Waterbal Indische waterlelie



NEW



1027242
Muzikale paddenstoel



Sprookjesbos