

LUVILLE®

LONDRES

AMSTERDAM

BRUXELLES

PARIS

STRASBOURG

The
LUVILLE
EXPRESS
since 1875

1875

CENTRAL

Vienne
Londres

Collection 2014





Table of Contents








ORIGINALS

Luville Express	5
Houses of Schneewald	17
Figurines of Schneewald	21
Houses of Ville de Reidy	27
Figurines of Ville de Reidy	32
Houses of Molendam	36
Figurines of Molendam	39
Santa's	41
Figurines Animal	43
Figurines in set	45
Sceneries	47
Houses Efteling	68
Figurines Efteling	74
Sceneries Efteling	76
Accessoires Efteling	78
Animated Efteling	80
Display Efteling	81
Lights & Fences	82
Adapters & Spare bulbs	96
Trees	98
Trees with lights	106
Landscape	111
Starterkits & Lanterns	112
Animated	117

COLLECTABLES

Waterglobes	141
Musicboxes	151
SPECIALS	
Animated	157
Houses	169

Explanation of icons

 Battery operated	 With music
 Led lighted	 Rotating item
 Lighted flame	 Moving item
 Runs with water	

Attention

The items shown and the descriptive specifications are the copyright of Edelman B.V. and may not be copied or reproduced without the required permission. Colour of the photographed models in the catalogue may deviate from the colours of the products due to lighting variations and the photographic session. Whilst every effort is made to ensure accuracy in this catalogue, mistakes do occur.



Packaging



ORIGINALS



COLLECTABLES



SPECIALS



LUVILLE®

ORIGINALS



The
LUVILLE[®]
EXPRESS
since 1875

In the early hours of a cold winter morning, a light already shines in the house of Pierre.



*Today is an exciting day;
he will be going on a journey.*

His suitcases are already packed and waiting in the hallway of the small farm home. Luckily his son, Philippe, will help to lift the heavy luggage into the carriage. The carriage is a little late and Pierre listens impatiently if he can hear it's arrival. He still has a long way to go to the station on the bumpy roads of the countryside. Suddenly he hears the hooves of a horse, and the coach finally arrives! Hopefully he will make it to the station on time.

On his way suddenly the carriage comes to a halt and a gentleman walks over and asks for some money. The last road to the station is a toll road and they are almost there..

They have arrived. The Coachman hands the suitcases to the Luggage Carrier who will help Pierre to carry them to the platform. It is busy at the station, and the steam from the locomotive streams down the hall. Pierre stands in line at the kiosk to buy a ticket and also buys a newspaper from a Street Vendor.




*He looks around; people are kissing each other goodbye,
and men in top hats walk towards the train.*

His suitcases are loaded on board and it's time to go.








611041
Auberg de Brux
 lighting adapter included
 AC 12V

-  With music
-  Rotating item
-  Led lighted



611042
Train Station
 lighting adapter included
 AC 12V

-  With music
-  Rotating item
-  Led lighted



611087
Children waiting for
train



611088
Pump rolley



611089
Kissing goodbye



611090
Railway guard Felix



611091
Newspaper street
Hawker



611092
Leon in a hurry



611097
Train timelabel



611100
Track pointer



611098
Station clock



611099
Waiting at the station
bench



611101
Advertising pillar



611102
Barrels



611103
Boxes



611104
Suitcases



611105
Cross road railway



611107
Little station bench



611108
Railway level crossing





611060
Luggage cart





611061
Ticket kiosk
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)



611062
Coach with luggage
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

 Battery operated
 Led lighted



 Battery operated
 Led lighted



611063
Coffee and sweets cart



611064
Tollhouse with barrier
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527 (adapter not
included)


-  Battery operated
-  Led lighted




611156
Steam locomotive



611157
Steam locomotive



168998
Extension pack B



168999
Extension pack C



Schneewald

As the sun disappears behind the mountains, two friends Dieter and Bernard glide down the mountain after a chilly and wonderful day of skiing.

The lights in the village have been lit in anticipation for the cold night ahead.



In front of the Snowy Owl Church they see Tom with his Grandfather finishing a newly built snowman. It has pebbles for eyes and a carrot for a nose.

*Dieter takes off his hat and places it on the snowman.
"And now he also has a hat!"*

Tom and his Grandfather laugh, for now their snowman is finished! Tom's Grandfather treats the two friends to a pretzel and a glass of mulled wine at the Christmas Market. The stalls are all wonderfully lit and there is a large Christmas tree in the centre of the square. Loud, cheerful music greets them from the street of the village.





And through the falling snow, they see an orchestra playing tunes in front of an Apres Ski café.

People are laughing, dancing and drinking and the waitresses are serving large pints of beer to happy guests. It is very busy, as many villagers have decided to stay and enjoy the cheerful atmosphere of the village. The two friends Dieter and Bernard decide to end day with a party.








611022
Hein's Bakery
led lighting battery operated with adapter connection fits to 4,5 v transformator 605524 (adapter not included)

-  Battery operated
-  Rotating item
-  Lighted flame
-  Led lighted






611024
Snow owl chapel
led lighting battery operated with adapter connection fits to 4,5 v transformator 605524 (adapter not included)

-  Battery operated
-  Rotating item
-  Led lighted





611028
Santa's House
lighting adapter included AC 12V

-  With music
-  Rotating item
-  Led lighted

Houses Schneewald





608227
Alpenrose barn
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Led lighted





609062
Santas home
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Led lighted



609067
Owl church
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)




-  Battery operated
-  Led lighted





610005
Beer Hütte
lighting, adapter included AC 12 V





610006
Blume Bauernhof
lighting, adapter included AC 12 V

-  With music
-  Rotating item
-  Led lighted

-  Rotating item
-  Led lighted






610007
Blackforrest farm
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Led lighted



610008
Church St. Fried
lighting, adapter included AC 12 V

-  Led lighted
-  Rotating item
-  With music



611070
Ted falls from
his sledge



611071
Fun on sledge





611072
Snowboarder
Mathijs



611073
Snowboarder
Ray



611106
Lighted Snowmen
led lighting battery
operated with adapter
connection fits to 3 V
transformator 605527
(adapter not included)

-  **Battery operated**
-  **Led lighted**



611074
Tony drinks Beer



602571
Gunther and
Lutz walking,
set of 3



603027
Just married



603034
Laura and
Martin with their
little brother



603063
Joselle and
Lissie in snow



603064
Children having
snowfun, set of 2



603067
Ann and Hein
building



604029
Birte & Jochem



604034
Niels jumping



604038
Making a
Snowman



608246
Ana and Mr
Snowman



608247
Tom and
grandfather in
the snow



608248
Sophie having a
ski lesson



608249
Ski class,
set of 3



608250
Frank with
Teddy on sledge



608253
Tandem Ski



608258
The sledge parade,
set of 3



609113
Ski jumpers,
set of 2



609114
Blas Orchester,
set of 2



609120
Ski Break



610055
Jerome the Falconer



610063
Melty the Snowman



610064
Rob and Tom's
Snowfight



610065
Eelco and Hubert



610066
Wendy and Reina
Oktoberfest



610067
Eric and Jules
Skiing



610068
Evi and rescue
dog having fun



Ville de Reidy

In the early hours of a cold winter morning, a light already shines in the house of Pierre.



*Today is an exciting day;
he will be going on a journey.*

His suitcases are already packed and waiting in the hallway of the small farm home. Luckily his son, Philippe, will help to lift the heavy luggage into the carriage. The carriage is a little late and Pierre listens impatiently if he can hear it's arrival. He still has a long way to go to the station on the bumpy roads of the countryside. Suddenly he hears the hooves of a horse, and the coach finally arrives! Hopefully he will make it to the station on time.

On his way suddenly the carriage comes to a halt and a gentleman walks over and asks for some money. The last road to the station is a toll road and they are almost there..

They have arrived. The Coachman hands the suitcases to the Luggage Carrier who will help Pierre to carry them to the platform. It is busy at the station, and the steam from the locomotive streams down the hall. Pierre stands in line at the kiosk to buy a ticket and also buys a newspaper from a Street Vendor.




*He looks around; people are kissing each other goodbye,
and men in top hats walk towards the train.*

His suitcases are loaded on board and it's time to go.







**611019
Sawmill**
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Moving item
-  Led lighted







**611020
Donkey Farm**
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Led lighted





**611021
Black Smith**
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Rotating item
-  Lighted flame
-  Led lighted





608236
Jardin Bellevue
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Led lighted





608238
L'Eglise de Reidy
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Led lighted





609069
Farmers Market
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Led lighted





**609070
Shepherd Home**
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Led lighted





**609073
St Karina Church**
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Led lighted



**609074
Charcuterie**
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Led lighted





610000
Ivy Home
lighting adapter included
AC 12V

 Led lighted





610002
Green Cabbage Market
lighting adapter included
AC 12V

 Rotating item
 Led lighted





610003
Church St Chevalier
led lighting battery operated with adapter
connection fits to 4,5 v transformator 605524
(adapter not included)

-  Battery operated
-  Led lighted



610004
Le Champinons
lighting adapter included
AC 12V

-  Rotating item
-  Led lighted



611065
Henry the
Lumberjack



611066
Egbert and Liesje
Falling



611067
Pigeon Lady



611068
Duval and Norah
eating chicken



611069
Two Farmer Boys



604039
Yann with Goats,
set of 2



604040
Juul and Elle
Feeding, set of 2



608263
Eating Apples



609125
Walking dogs
service



610052
Herman and Timo,
Set of 2



610053
Grandpa and
Grandma



610056
Doing laundry
with tubbs



610057
Marius helping
Gerbert



Molendam

As night falls and it begins to snow and a beautiful white layer adorns the village.



*And in it's heart, the Lantern Lighter
lights his last match.*

The lanterns magically shine light on the bakery down the alley. As Farmer Bert and his wife Klazien guide the cows inside their three sons load the cheese that is to be delivered to the church tonight.

The Cheese Farm is next to the Windmill that belongs to Piet. And in the softly lit house next door, Piet is inside putting on his ice-skates.

*Before dinner he will go for a long skate
around the lake next to the Windmill.*

It is also very busy with many other iceskaters and you can hear the ice cracking under the skates. And children from the village bring and sell hot pea soup along the quay.

In the village people are preparing for the evening. The aromas of freshly baked pancakes, as well as Jan and Jaap's smoked eel, wander through the quaint streets. All are warm and cosy in their homes, in this cold Dutch winter.








611025
Pancake home
lighting adapter included
AC 12V









611026
Church choir
lighting adapter included
AC 12V



611027
Cheese farm
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)



-  With music
-  Rotating item
-  Led lighted

-  With music
-  Rotating item
-  Led lighted

-  Battery operated
-  Rotating item
-  Led lighted





608243
The Horsemill
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Led lighted





609077
Bakery
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Led lighted






609078
St Victor church
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Led lighted







609080
Eel smokehouse
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Lighted flame
-  Led lighted



610009
Chicken Farm Kukeleku
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Rotating item
-  Lighted flame
-  Led lighted



611075
Ice skater Thijs



611076
Children ice skating



611077
Hopscotch



611078
Farmers wife Mara



611079
Mom is doing hand wash



602552
S3 Sinterklaas



608288
Snowfighters





609134
Baker on bike



609133
Milk cart



609132
Lantern lighter
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adaptr not included)

-  Battery operated
-  Led lighted



609138
Eel smokers



610071
Henk the cow milker



611085
Dogs teasing Santa



611086
Santa's gift box



604023
Santa skiing



604024
Santa with deer



608252
Santa's mailbox



609112
Little Santa



609115
Santa with baby



609116
Santa with big present



610062
Santa checking his list



610095
Santa singing



602568
Santa with Deer



611080
Horse and Dog
fun



611081
Dogs,
set of 2



611082
Cats,
set of 2



611083
Sheep and Goat,
set of 2



611084
Peacock and
Pheasant,
set of 2



600301
Deer with Rabbit,
set of 2



603044
Deer drinking



609146
Wintersheep,
set of 2



610075
Goose with
babies



610077
Playing Goats



610078
Pigs at the fence



610079
Jack with Foal



610080
Flying Ducks,
set of 3



604047
Assortment ii, set of 12



609197
Animals, set of 8





609198
Figurines, set of 12



609200
Figurines, set of 7





**611045
Priest Chapel**
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted





**611046
Apres Ski Tent**
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted



**611048
Poulrier Market**
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Led lighted





611047
Blacksmith Life



611049
Beer Cart





611050
Luuk is carving wood
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527 (adapter not
included)

-  Battery operated
-  Led lighted





611051
Pigeon House
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted





611052
Campfire cave
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted





611053
Ski route
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted



**611054
Pretzel Market**
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  **Battery operated**
-  **Led lighted**



**611055
Winter Dog sledge**



**611056
Donkey cart**



611057
Dutch little cheese house



611058
Santa feeds Rudolf



611059
Little children's farm





611060
Luggage cart





611061
Ticket kiosk
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)



611062
Coach with luggage
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

 Battery operated
 Led lighted



 Battery operated
 Led lighted



611063
Coffee and sweets cart



611064
Tollhouse with barrier
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527 (adapter not
included)

-  Battery operated
-  Led lighted



600366
Stone Bridge with deer





611093
Work table



600389
Village well



611095
Ice Bridge
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted



603023
Santa Reindeer sledge



603024
Santa gifts



604026
Cookie stand




608289
Christmas shed



608290
Chapel
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

 Battery operated

 Led lighted





608294
Apresski Hut



608343
Oliebollenkraam





609095
Gluhwein shed
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted





609097
Christmas tree seller
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted



609099
Chapel
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted





609100
Farm scenery,
set of 4



609105
Santa with reindeer






609106
Skate rental
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted



609107
Campfire skiing, set of 4
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)



-  Battery operated
-  Lighted flame
-  Led lighted



609109
Deer cart





610033
Eel Smokeshed, set of 3
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted





610034
Christmas market pretzels
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted





610115
Christmas market bierstube
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted



610116
Christmas market bratwurst
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted






610036
Farm life, set of 3



610037
Merry forest, set of 2



610040
Nature campfire
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Lighted flame
-  Led lighted





610041
Reindeer teasing Santa



610042
Little chicken farm



610043
Alps chapel
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted





610044
Kaasbrik



610045
Stempelpost
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)



610046
Vegetables market

-  Battery operated
-  Led lighted



610047
Haystack shed



610048
Flower market



610050
Dog sledge





Efteling

ANTON PIECK





381545
Castle Sleeping Beauty
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Led lighted





381645
House Gnomes
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Led lighted

Efteling
ANTON PIECK





381646
House Roodkapje
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Led lighted



381880
House of the 7 Goats
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)



-  Battery operated
-  Led lighted

Houses Efteling

Efteling
ANTON PIECK





381881
House Hans and Grettel
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  **Battery operated**
-  **Led lighted**



381882
House of the Gnomes
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)



-  **Battery operated**
-  **Led lighted**

Houses Efteling

Efteling
ANTON PIECK





381883
House Tobbelientje
lighting, adapter included AC 12 V

-  Rotating item
-  Led lighted



381884
House Repelsteeltje
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)



-  Battery operated
-  Led lighted

Houses Efteling

Efteling
ANTON PIECK






381885
House of Vrouw Holle
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Led lighted





381937
Music Gnome
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Lighted flame
-  Led lighted

Houses Efteling





381938
Tower Raponsje
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Led lighted



381939
King of Trolls
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Led lighted

Efteling
ANTON PIECK



381500
Little Red Ridinghood



381502
Fishing Dwarf



381501
Knight



381503
Dancing Dwarf



381886
The Wolf



381887
Mother Goat

Figurines Efteling

Efteling
ANTON PIECK



381888
Tobbelientje



381940
Holle Bolle Gijs



381942
Gnome writing

Efteling
ANTON PIECK



381892
Little Message



381895
Ezeltje Strekje



381896
Oven Hans and Gretel



381897
Fairytale Forest

Sceneries Efteling



381898
Well Vrouw Holle



381899
Bridge Tobbelientje



381924
Arch Doornroosje

Efteling
ANTON PIECK



381650
Wastebin



381651
Mushroom



381652
Bench





381653
Fence



381904
Sign





381905
Lighted tree
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted

Accessoires Efteling





381932
Lantern wood
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted






381934
Lantern iron
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted

Efteling
ANTON PIECK



381925
Lighted street Zwaan kleef aan
lighting adapter included AC 12V




-  With music
-  Rotating item
-  Led lighted

Animated Efteling

Efteling
ANTON PIECK





381910
Display Efteling
lighting adapter included AC 12V

-  With music
-  Rotating item
-  Led lighted

Display Efteling





 Battery operated
 Led lighted



611094
Moon
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)





 Battery operated
 Led lighted



611096
Skilift lanterns
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)





611191
Lighted fence
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

 Battery operated
 Led lighted





611192
Lighted gate & fence
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

 Battery operated
 Led lighted





611193
Set of 2, Signal light
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted





611194
**Lighted wooden gate
with wreath**
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted






611195
**Birdcage with old English
street lantern**
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted





605090
36 Mini lights blue
led lighting battery operated with adapter connection fits to 3 V transformer 605527 (adapter not included)

 **Battery operated**
 **Led lighted**






605106
36 Mini lights white
led lighting battery operated with adapter connection fits to 3 V transformer 605527 (adapter not included)

 **Battery operated**
 **Led lighted**





605091
36 Mini lights white
led lighting battery operated with adapter connection fits to 3 V transformer 605527 (adapter not included)

 **Battery operated**
 **Led lighted**





605107
36 Mini lights multicolor
led lighting battery operated with adapter connection fits to 3 V transformer 605527 (adapter not included)

 **Battery operated**
 **Led lighted**





605092
36 Mini lights multicolor
led lighting battery operated with adapter connection fits to 3 V transformer 605527 (adapter not included)

 **Battery operated**
 **Led lighted**





605116
White spotlights, set of 3
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted





605117
Blue spotlights, set of 3
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted





610155
Spot lights, set of 2
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted





605125
Victorian streetlamp, set of 4
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Lighted flame





605126
Streetlantaarn, set of 4
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Lighted flame





605131
Globe streetlantern, set of 2
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Lighted flame





605127
Gas streetlantern, set of 4
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Lighted flame





605128
Gas streetlamp, set of 6
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Lighted flame



605129
Gas streetlantern, set of 8
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Lighted flame



 Battery operated



605132
Old English street, set of 2
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)



 Battery operated



605133
Boulevard street, set of 2
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)




605149
Lantern, set of 4
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

 Battery operated



609150
Iron lantern, set of 3
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

 Battery operated





605052
Wooden fence green tree,
set of 2





609151
Wooden fence



609153
Waterpump





609148
Wooden lantern, set of 3
 led lighting battery operated with
 adapter connection fits to 3 V
 transformer 605527
 (adapter not included)

-  Battery operated
-  Led lighted





609149
Wooden/iron lantern, set of 3
 led lighting battery operated with
 adapter connection fits to 3 V
 transformer 605527
 (adapter not included)

-  Battery operated
-  Led lighted





609185
Wooden lantern, set of 3
 led lighting battery operated with
 adapter connection fits to 3 V
 transformator 605527
 (adapter not included)

-  Battery operated
-  Led lighted





609186
Lantern with bird, set of 3
 led lighting battery operated with
 adapter connection fits to 3 V
 transformator 605527
 (adapter not included)

-  Battery operated
-  Led lighted






610180
Wooden streetlantern, set of 4
 led lighting battery operated with
 adapter connection fits to 3 V
 transformator 605527
 (adapter not included)

-  Battery operated
-  Led lighted






609184
Fire chasing
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted
-  Lighted flame






610092
Fire with cookpot
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted
-  Lighted flame





610093
Little fire
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted
-  Lighted flame





610094
Chinese lantern light chain
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  **Battery operated**
-  **Led lighted**





610118
Chinese lantern light chain
yellow
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  **Battery operated**
-  **Led lighted**





610120
Chinese lantern light chain
multicolor
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  **Battery operated**
-  **Led lighted**





610098
Lighted tree warm white
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted



610099
Lighted tree multicolor
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)



-  Battery operated
-  Led lighted



610158
Fence with lightchain
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)



610159
Fence

-  Battery operated
-  Led lighted



605523
Clear E10 12V
replacement bulb,
set of 2



609178
Led spare bulbs,
set of 2



609179
Led spare bulbs,
set of 4



609180
Led spare bulbs,
set of 6



609177
Led light bulb



610153
Chain of 3 led light bulbs
led lighting battery operated with adapter connection fits to 4,5 v transformer 605524 (adapter not included)



610154
Chain of 6 led light bulbs
led lighting battery operated with adapter connection fits to 4,5 v transformer 605524 (adapter not included)



610300
Switch adaptor with 4 plug output 16.9



610301
Light cord with switch adaptor 16.9



610302
4.5volt switch adaptor with 4 plug out



610303
10 din lightsystem with switch adaptor



611184
23 cm H
Tree with snow



611185
15 cm H
Tree with snow



611189
23 cm H
Tree with snow



611190
15 cm H
Tree with snow



605000
Bristle tree XI
H 30 cm



605001
Bristle tree L
H 23 cm



605002
Bristle tree M
H 15 cm



605003
Bristle tree S
H 10 cm, set of 2



605019
Evergreen tree Jumbo
H 40 cm



605020
Evergreen tree XI
H 30 cm



610179
Assorted trees,
set of 21



605005
Bristle tree assorted,
set of 21



605006
Bristle tree assorted,
set of 12



605048
Winter Alaska Pine XI
H 30 cm



605049
Winter Alaska Pine L
H 23 cm



605050
Winter Alaska Pine M
H 15 cm



605009
Mountain Pine S
H 10 cm, set of 2



608317
Buxus Evergreen Tree
H 6 cm, set of 2



605004
Bristle Tree Mini
H 8 cm, set of 8



608318
Evergreen Tree,
set of 9



608319
Bristle Tree,
set of 9



608320
White Tree,
set of 9



609158
Evergreen Tree,
set of 21



609159
Tree White,
set of 21



609176
Tree Evergreen,
set of 12



609194
Tree willow snow
H 16 cm



609195
Tree willow snow
H 23 cm



610096
Maple tree snowed
H 15 cm



610097
Maple tree autumn
H 15 cm



610169
Mountain pines on base
H 13 cm




610170
Alaska pines on base
H 10 cm



610171
Alaska pines on base
H 15 cm



 Battery operated



611181
Tree with snow & warm white led light, H 15 cm
led lighting battery operated with adapter connection fits to 3 V transformer 605527 (adapter not included)




 Battery operated



611182
Tree with warm white led light, H 23 cm
led lighting battery operated with adapter connection fits to 3 V transformer 605527 (adapter not included)




 Battery operated



611180
Tree with snow & warm white led light, H 23 cm
led lighting battery operated with adapter connection fits to 3 V transformer 605527 (adapter not included)



 Battery operated



611179
Lighted tree (warm white)
led lighting battery operated with adapter connection fits to 3 V transformer 605527 (adapter not included)



 Battery operated



611183
Tree with warm white led light, H 15 cm
led lighting battery operated with adapter connection fits to 3 V transformer 605527 (adapter not included)



 Battery operated



605079
Shimmering twig tree
fibre optic H 23 cm
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)



 Battery operated



605080
Shimmering twig tree
fibre optic H 18 cm
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)




 Battery operated



605070
Shimmering pine
fibre optic H 23 cm
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)




611186
6 Bristle trees on stone wall
with led light
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

 Battery operated



611187
4 Bristle trees on stone wall
with led light
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)


 Battery operated



611188
5 Winter Alaska pine on stone
wall with led light
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

 Battery operated



 Battery operated



609162
6 Trees on base multicolor
H 19 cm

led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)



 Battery operated



609163
6 Trees on base led light
H 19 cm

led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)




 Battery operated



609164
6 Trees on base led light
H 19 cm

led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)



 Battery operated



609165
3 Trees on base led light
H 19 cm

led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)



 Battery operated



609166
Trees on base fibre optic light
H 19 cm

led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)



 Battery operated




609167
3 Trees on base led light
H 19 cm

led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)



608312
Christmas tree with light
H 15 cm, set of 3
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

 **Battery operated**




605071
Bristle tree H 23 cm
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

 **Battery operated**




605142
Christmas tree with light
H 15 cm
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

 **Battery operated**




608311
Tree with light large H 23 cm
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

 **Battery operated**



605143
Christmas tree with light
H 23 cm
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

 **Battery operated**



608310
Christmas tree with light
H 15 cm, set of 2
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

 **Battery operated**



 Battery operated



610157
Mini Boxwood in pot
H 13 cm, set of 2
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)




 Battery operated



609171
Tree led light white
H 23 cm
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)



 Battery operated



609183
Tree led light multicolor
H 23 cm
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)



 Battery operated



610150
Lighted trees with fence
H 21 cm
led lighting battery operated with
adapter connection fits to 3 V trans-
formator 605527
(adapter not included)




 Battery operated



610151
Lighted tree
H 19 cm
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)



 Battery operated



610152
Lighted tree on wood base
H 23 cm
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)



610090
Street path, corner,
set of 2



610091
Stone path, corner,
set of 2



610089
Sand path, corner pieces,
set of 2





605135
Green lawn with snow



610172
Hay bales,
set of 20





609208
Starterskit Type 1A, set of 12
 led lighting battery operated with adapter
 connection fits to 3 V transformator 605527
 (adapter not included)

-  Battery operated
-  Led lighted





609209
Starterskit Type 1B, set of 12
 led lighting battery operated with adapter
 connection fits to 3 V transformator 605527
 (adapter not included)

-  Battery operated
-  Led lighted





609210
Starterkit Type 1C, set of 12
led lighting battery operated with adapter
connection fits to 3 V transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted



609211
Starterkit Type 2A. set of 12
led lighting battery operated with adapter
connection fits to 4,5 v transformator 605524
(adapter not included)




-  Battery operated
-  Led lighted





609215
Starterskit Type 3B, set of 21
lighting adapter included AC 12V





609216
Starterskit Type 3C, set of 21
led lighting battery operated with adapter
connection fits to 4,5 v transformator 605524
(adapter not included)

-  Rotating item
-  Battery operated
-  Led lighted

-  Battery operated
-  Led lighted





610135
Starterkit B
led lighting battery operated with adapter
connection fits to 4,5 v transformator 605524
(adapter not included)

-  Battery operated
-  Led lighted





609218
Lantern 2
lighting adapter included AC 12V

-  Rotating item
-  Led lighted





609220
Lantern 4
lighting adapter included AC 12V

-  Rotating item
-  Led lighted





611125
Lantern with singing choir
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted





611126
Lantern with flaming fire
led lighting battery operated with
adapter connection fits to 3 V
transformator 605527
(adapter not included)

-  Battery operated
-  Led lighted







611127
Lantern with house
led lighting battery operated with
adapter connection fits to 4,5 v
transformator 605524
(adapter not included)

-  Battery operated
-  Led lighted






611029
Winter cave
led lighting battery operated with adapter
connection fits to 4,5 v transformator 605524
(adapter not included)

-  Battery operated
-  Rotating item
-  Lighted flame
-  Led lighted



611030
Apres ski tent
lighting adapter included AC 12V

-  With music
-  Rotating item
-  Led lighted



611031
Santa's factory
lighting adapter included AC 12V

- 🎵 With music
- ↻ Rotating item
- 💡 Led lighted






611032
Kabelbahn mountain
lighting adapter included AC 12V

- 🎵 With music
- ↻ Rotating item
- 💡 Led lighted







611035
Winter games
led lighting battery operated with adapter
connection fits to 4,5 v transformator 605524
(adapter not included)

-  With music
-  Battery operated
-  Rotating item





611036
Christmas melody
led lighting battery operated with adapter
connection fits to 4,5 v transformator 605524
(adapter not included)

-  With music
-  Battery operated
-  Rotating item
-  Led lighted





611038
Lighted Homestead Mill
lighting adapter included AC 12V

-  Rotating item
-  Led lighted






611039
Make a wish Well
led lighting battery operated with adapter
connection fits to 4,5 v transformator 605524
(adapter not included)

-  Battery operated
-  Rotating item






611040
Lighted snowmen with children
led lighting battery operated with adapter
connection fits to 4,5 v transformator 605524
(adapter not included)

-  Battery operated
-  Rotating item
-  Led lighted



610018
Santa flying
lighting adapter included AC 12V




-  With music
-  Rotating item
-  Led lighted






611044
Ballroom
lighting adapter included AC 12V





611043
Skating and skiing cave
lighting adapter included AC 12V

-  With music
-  Rotating item
-  Led lighted

-  With music
-  Rotating item
-  Led lighted






610019
Grain mill
lighting adapter included AC 12V

-  Rotating item
-  Led lighted



610020
Skating on the ditch
lighting adapter included AC 12V




-  With music
-  Rotating item
-  Led lighted





610022
Sledge mountain
lighting adapter included AC 12V





610023
Snow fight
lighting adapter included AC 12V

-  With music
-  Rotating item
-  Led lighted

-  Rotating item
-  Led lighted






610024
Blackforrest miniwheel
lighting adapter included AC 12V

-  Rotating item
-  Led lighted







610025
Forest swing
led lighting battery operated with adapter
connection fits to 4,5 v transformator 605524
(adapter not included)

-  Battery operated
-  Rotating item
-  Led lighted






610026
Little skate pond
led lighting battery operated with adapter
connection fits to 4,5 v transformer 605524
(adapter not included)

-  With music
-  Battery operated
-  Rotating item
-  Led lighted



610028
Ferris wheel
lighting adapter included AC 12V

-  Rotating item
-  Led lighted
-  With music



610031
Carousel
lighting adapter included AC 12V

- 🎵 With music
- ↻ Rotating item
- 💡 Led lighted



610030
Carousel
lighting adapter included AC 12V

- 🎵 With music
- ↻ Rotating item
- 💡 Led lighted



610029
Express
lighting adapter included AC 12V

Rotating item
Led lighted






600074
Lakeside wooden windmill
lighting adapter included AC 12V

Rotating item
Led lighted






603038
Ski lift
lighting adapter included AC 12V

-  With music
-  Rotating item
-  Led lighted






603080
Swing Santa
lighting adapter included AC 12V

-  With music
-  Rotating item
-  Led lighted





604011
Ski slope
lighting adapter included AC 12V

-  With music
-  Rotating item
-  Led lighted






604043
Santa is falling
lighting adapter included AC 12V

-  With music
-  Rotating item







604045
Seesaw
led lighting battery operated with adapter
connection fits to 4,5 v transformator 605524
(adapter not included)

-  Battery operated
-  Rotating item
-  Led lighted





608215
Forest skating pond
lighting adapter included AC 12V

-  With music
-  Rotating item
-  Lighted flame
-  Led lighted





609081
Sleigh animation
lighting adapter included AC 12V

-  Rotating item
-  Led lighted





609082
Fountain
lighting adapter included AC 12V

-  Runs with water
-  Led lighted






609085
Dutch skating pond
lighting adapter included AC 12V

-  Rotating item
-  Led lighted






609087
Winter animation
lighting adapter included AC 12V

-  Rotating item
-  With music
-  Led lighted





609088
Santas factory
lighting adapter included AC 12V

-  With music
-  Rotating item
-  Led lighted





609090
Farm mill animated
lighting adapter included AC 12V

-  Rotating item
-  Led lighted





609091
River mill animated
lighting adapter included AC 12V

-  Rotating item
-  Led lighted



609092
The Dutch tulip mill
lighting adapter included AC 12V



-  Rotating item
-  Led lighted






609094
Animated mountain & water village
 lighting adapter included AC 12V



610013
Horse riding in little
 lighting adapter included AC 12V

-  Runs with water
-  Led lighted

-  With music
-  Rotating item
-  Lighted flame




Animated






610014
Ski cave
lighting adapter included AC 12V







610015
Water forest
lighting adapter included AC 12V

-  With music
-  Rotating item
-  Led lighted

-  Rotating item
-  Runs with water
-  Led lighted





610016
Winter sports mountain
lighting adapter included AC 12V

-  With music
-  Rotating item
-  Lighted flame
-  Led lighted



610017
Farmers mill
lighting adapter included AC 12V

-  Rotating item
-  Led lighted





611129
Waterglobe penguin

🎵 With music



611130
Waterglobe bear

🎵 With music



611140
Waterglobe deer

🎵 With music



610123
Waterball Santa with top hat



610124
Waterball Snowman



611138
Musical Snowman
with gifts hat base
waterglobe

🎵 With music

🎵 With music

🎵 With music



611141
Santa with reindeer revolving
musical waterglobe

Rotating item
With music



611142
Houses with train revolving
musical

Rotating item
With music



611143
Two girls making Snowman

With music



611144
Reindeer with church

🎵 With music



611145
Children with fruits

🎵 With music



611146
Santa with gifts

🎵 With music



374725
Waterball Santa
with Christmas tree

🎵 With music



611147
Christmas snowdome
Santa in tree

🌀 Rotating item
🎵 With music



611139
Christmas snowglobe
with Santa in tree

🌀 Rotating item
🎵 With music



611133
Christmas tree revolving

Rotating item
With music



611134
Christmas bells and garland
with horse

With music



611135
Christmas musical carousel

Rotating item
With music



611136
Musical Nutcracker waterball

🎵 With music



611137
Musical carousel with base revolving waterball

🌀 Rotating item
🎵 With music



181021
Waterball Christmas tree

🎵 With music



181030
Waterball Fairy & Nutcracker

🎵 With music



609236
Waterball Santa and reindeer

🎵 With music




609237
Waterball snowy village

🎵 With music



609238
Waterball singing family

🎵 With music



610125
Waterball playing children

🎵 With music






610126
Waterball Santa with reindeer

🎵 With music



611109
Windup Musicboxes, 3 assortment
 led lighting battery operated with adapter
 connection fits to 4,5 v transformator 605524
 (adapter not included)

-  With music
-  Battery operated
-  Rotating item



611110
Musicbox circus
lighting adapter included AC 12V

Rotating item
With music







611111
Musicbox winter
lighting adapter included AC 12V

Rotating item
With music







611115
Lantern snowfun
led lighting battery operated with adapter
connection fits to 4,5 v transformator 605524
(adapter not included)

-  With music
-  Battery operated
-  Rotating item
-  Led lighted



611116
Lantern Santa
led lighting battery operated with adapter
connection fits to 4,5 v transformator 605524
(adapter not included)

-  With music
-  Battery operated
-  Rotating item
-  Led lighted



181009
Merry-Go-Round
D 16 cm

Rotating item
With music



181010
Merry-Go-Round
D 19 cm

Rotating item
With music



181011
Merry-Go-Round
D 19 cm

Rotating item
With music



181012
Merry-Go-Round
D 25 cm

Rotating item
With music



181018
Christmas tree

Rotating item
With music



181019
Christmas tree with presents

Rotating item
With music






LUVILLE®

SPECIALS





611000
Christmas village, 2 assortment
adapter connection included

-  Battery operated
-  Rotating item
-  Led lighted






611001
Tree trunk with scenery, 3 assortment
adapter connection included

-  Battery operated
-  Led lighted






611002
Christmas scenery, 2 assortment
adapter connection included

-  Battery operated
-  Rotating item
-  Led lighted






611003
Christmas scenery with
playing kids
adapter connection included

-  Battery operated
-  Rotating item
-  Led lighted






611005
Christmas scenery
with a Snowman
adapter connection included

-  Battery operated
-  Rotating item
-  Led lighted



611006
Christmas scenery
with skating kids
adapter connection included




-  Battery operated
-  Rotating item
-  Led lighted




611008
Christmas train
adapter connection included






611009
Ferris wheel
including adapter

-  Battery operated
-  Rotating item
-  Led lighted

-  Rotating item





611010
"Santa's Truck"
adapter connection included

-  Battery operated
-  Rotating item
-  Led lighted



611012
House with Christmas scenery
including adapter

-  With music
-  Rotating item



611013
Lighted street
including adapter

🎵 With music
↻ Rotating item






611014
Ski slope
including adapter

↻ Rotating item






167486
Winter ski slope
adapter connection included

-  Battery operated
-  Rotating item
-  Led lighted





167487
Tree trunk, 2 assortment
adapter connection included

-  Battery operated
-  Rotating item
-  Led lighted






167488
Ski lift
including adapter

-  Rotating item
-  Led lighted



167490
Winter village with train,
2 assortment
adapter connection included




-  Battery operated
-  Rotating item
-  Led lighted







167494
Lighted street, 2 assortment
adapter connection included



611118
Santa's scenery, 2 assortment
adapter connection included

-  Battery operated
-  Rotating item
-  Led lighted




-  With music
-  Battery operated
-  Lighted flame
-  Led lighted







611119
Village with turning skaters
adapter connection included






611120
Village with moving train
adapter connection included

-  Battery operated
-  Rotating item
-  Led lighted

-  With music
-  Battery operated
-  Rotating item
-  Led lighted






611121
Church, fiber optic
adapter connection included

-  With music
-  Battery operated
-  Led lighted



611122
Church fiber optic
adapter connection included

-  With music
-  Battery operated
-  Led lighted





611123
Mountain, fiber optic
including adapter

 Moving item
 Led lighted



611124
Christmas village, fiber optic
including adapter

 Rotating item
 Led lighted





611015
Led house
adapter connection included







611016
Led house
adapter connection included



611017
Led house
adapter connection included

 Battery operated
 Led lighted

 Battery operated
 Led lighted

 Battery operated
 Led lighted





611018
Led house
adapter connection included







610127
Led house
adapter connection included



610128
Led house
adapter connection included

 Battery operated
 Led lighted

 Battery operated
 Led lighted

 Battery operated
 Led lighted





610129
Led house
adapter connection included







610130
Led house
adapter connection included



610131
Led house
adapter connection included

 Battery operated
 Led lighted

 Battery operated
 Led lighted

 Battery operated
 Led lighted





611117
Christmas led house
adapter connection included







611151
Christmas led house
adapter connection included



611152
Christmas led house
adapter connection included

 Battery operated
 Led lighted

 Battery operated
 Led lighted

 Battery operated
 Led lighted





611153
Christmas led house
adapter connection included





611154
Christmas led house
adapter connection included



611132
Adapter

 Battery operated
 Led lighted

 Battery operated
 Led lighted

Notes

A series of horizontal dotted lines for writing notes.

Contact

Asia	Stephane Hasselsweiler	t: (+852) 671 91 721
Austria	Werner Ungerhofer	t (+ 43) 66 440 041 52
	Ans Rutte	t: (+31) 651 405 498
Belgium & Luxembourg	Stefan Bossers	t: (+32) 476 415 293
Eastern Europe	André Theuns & Jenneke Meerman	t: (+31) 182 398 200
Finland	Michael Rijnen	t: (+358) 4565 04 233
France	Robin van Gerven	t: (+31) 182 398 200
Germany	Michael Bollmann	t: (+49) 170 802 89 14
Ireland	Ian Barton	t: (+353) 87 258 3350
Italy	Fabio Casotto	t: (+39) 335 39 3454
The Netherlands	Esther Oomen	t: (+31) 182 398 200
Spain & Portugal	John Duijvestijn	t: (+34) 609 101 501
	Menno Lachmeijer (Catalunia)	t: (+34) 977 606 876
Norway, Sweden, Denmark	Ann Söderberg	T: (+46) 705 693 390
Iceland & Baltic States		
Poland	Marian Kaczorowski	t: (+48) 507 168 821
Switzerland	Michael Bollmann	t: (+49) 170 802 89 14
U.S.A.	André Theuns	t: (+31) 182 398 200
United Kingdom	André Theuns	t: (+31) 182 398 200

Offices Edelman:

Headoffice Edelman B.V.

Schinkeldijk 56
2811 PB Reeuwijk, the Netherlands
P.O. Box 40
2810 AA Reeuwijk, the Netherlands
t: (+ 31) 182 398200
e: info@edelman.eu

Edelman Asia Ltd.

7/F Block B. Eldex Industrial Building
21 Ma Tau Wai Road
Hungom, Kowloon, Hong Kong
t: (+852) 27744112
e: info@edelmanasia.com.hkk